


## 4532 Siena Medium Dining Table

Thank you for purchasing this Siena Dining table. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



This item is **HEAVY** 



## Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you purchased this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.


This product takes approximately **20 MINUTES** to assemble with **2 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Ref: 00237/4532


## Fittings and parts checklist

Α	Table top × I	E	Allen key x I
В	Left legs × 2	F	Locking washer x 12
С	Right legs × 2	G	Flat washer x 12
D	45mm Bolt × 12		




## Step by step assembly instructions

1. Assemble the left legs (B) and right legs (C) as shown below.



2. Two people may be required to carefully turn the table top face down onto a smooth soft surface such as carpet. Put one set of legs to the table top and matching the holes, secure the bolts and washers (locking washer first) into the legs through the holes on the end rail of the table top. When ALL bolts and washers are in place, hand tight. Repeat with the other set of legs.



3. After assembling the legs, and with the aid of another person, carefully lift the table and turn it over. Do not to turn the table over on two legs as this may cause damage. Please take care as this table is very heavy.

