


ercol

382 plank table & 3384 drop leaf table

Thank you for purchasing this plank table or drop leaf table. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

Necessary Tools




Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.



The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.


Fittings and parts checklist

A	M6 x 40mm connecting bolt x 16 (for each table)	
B	Allen key x 1 (for each table)	


Step by step assembly instructions



C underframe, see below.



382 plank table



3384 drop leaf table Positionss for the connecting bolts (A) are the same as for the plank table, see previous diagram.

Step by step assembly instructions

1. Lay the table top face down on to a soft surface such as carpet or a blanket which is free from sharp objects.
 2. Using the 16 M6 40mm bolts and the allen key supplied, first **partially** tighten each bolt of the leg assemblies onto the table top, see diagram above. When **all** bolts are in place tighten them all fully.
 3. Using two people carefully lift and turn to an upright position.
 4. Do not turn to an upright position by pivoting on the table legs.
 5. To extend the 3384 drop leaf table, lift each flap and pull out the extension support by it's handle (D)
-

General care

Furniture with a shiny surface should also be dusted with a soft cloth. Polish the surfaces using only natural bees wax a maximum of twice a year.

Spray polishes should not be used as they contain silicones which may spoil the furniture's surface by building up over time. Use of cleaning materials containing abrasive compounds, acidic or caustic reagents and any bleaches containing oxidising reagents should be avoided as prolonged use may damage

General care

the lacquered surface.

This furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

Warning

This unit is heavy use an assistant when lifting.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

Ercol Furniture Ltd, Summerleys Road, Princess Risborough, Bucks. HP27 9PX www.ercol.com